


If the power output of the controller is reached, increase the number of LEDs with the use of power amplifiers

Starscape
 7 Main Street Lowick, Berwick upon Tweed
 TD15 2UD. www.starceiling.co.uk
 01289 388399

The LED modules are followed by amplifiers in parallel.

Code: (STARPEM2)



The LED modules are followed by amplifiers in series.

